

TABELA ZAMIENNIKÓW BATERII													
G1	G2	G3	G4	G5	G6	G7	G8	G9	G10	G11	G12	G13	G0
AG1	AG2	AG3	AG4	AG5	AG6	AG7	AG8	AG9	AG10	AG11	AG12	AG13	AG0
LR60	LR59	LR41	LR66	LR48	X	LR57	LR55	X	LR54	LR58	LR43	LR44	LR63
LR621	LR126	LR736	LR626	LR754	LR920	LR927	LR1120	LR936	LR1130	LR721	LR1142	LR1154	X
LR620				LR750									
364	396	384	376	393	370	395	381	394	389	361	301	357	379
D364	D396	39K	377	D393	371	399	D381	D394	D389	D361	386	303	JA
D	397	S312E	D377	F			391	380	390	362	D, H	J, A	D379
	D397	MS312					D391		D390	D362	S41E	EPX76	
	V.N						L, 191		M, 189	S	186	A76 S76E	
SR60	SR59	SR41	SR66	SR48	SR69	SR57	SR55	SR45	SR54	SR58	SR43	SR44	SR63
SR621 SW	SR726 W	SR41 SW	SR626 W	SR754 W	SR920 W	SR927 SW	SR1120 SW	SR936 SW	SR1130 W	SR721 W	SR43 SW	SR44W	SR521 SW
SR621 W	SR726 SW	SR41W	SR626 SW		SR920 SW	SR927 W	SR1120S	SR936 W	SR1130 SW	SR721 SW	SR43 W	SR44 SW	
V364	V396	V384	SB-BW	V393	SB-BN	SB-AP/ BP	V381/391	V394	V389/ 390	SB-BK	V301	V357	618
GP364	V397	V392	SB-AW	546	SB-AN	280-44	533	524	554	SB-AK	V386	V303	280-259
SB-AG	GP396	247D	280-72	GP393	280-51	280-48	553	SB-A4	534	280-53	528	541	GP379
280-34	GP397	280-18	280-39	GP255	GP370	GP399	SB-AS	194	SB-BU/ AU	280-29	548	521	SB-AC
280-74	SB-BL	280-13	177	CX48	GP371	GP395	SB-BS	280-17	280-15/ 24	V362	226	SB-B9	V379
CX60	SB-AL	GP384	V377		171	V399	280-27	625	615	532	260	SB-A9	520
164	280-52	GP392	565		537	V395	280-30	GP394	601	SB-A8	GP357		
602	280-28	SB-A1	606		V371	543	GP381		603	GP362	SB-B8	GP303	
	556	SB-B1	GP377		605	523	GT-391		GP389/ 390	162	280-41	228	
	536	547			CX69	195	609		L1131	RW310	280-01	L1154	
	612	527				610	CX55		S1131	SR720	GP301	S1154	
	607	S/L736				CX927	L/S1121		GP189		GP389	V76PX	
						S28	SG8				L1142	GPS76 E	
							V8GA				S1142		
											1176A		